

Up-date for road maps takeMS traffic 43

Dear Sir or Madam,

We are offering a service in cooperation with www.naviextras.com for you where you can update your maps, 3 dimensional buildings, ...

Here's a step-by-step tutorial how to do that:

1. Download and install Microsoft ActiveSync 4.2
(<http://www.microsoft.com/downloads/details.aspx?familyid=7269173A-28BF-4CAC-A682-58D3233EFB4C&displaylang=en>).
2. Register at www.naviextras.com
(<https://www.naviextras.com/shop/portal/registration?task=register>).
3. Download and install the Naviextras Toolbox
(<https://www.naviextras.com/shop/portal/downloads>).
4. Restart your computer.
5. Start the Naviextras Toolbox.
6. Connect your navigation system using the USB cable included in the content package and start the navigation system.
7. Microsoft ActiveSync and the Naviextras Toolbox recognizes the navigation system automatically.
8. Sign in on the Naviextras Toolbox with your Account details you entered/got in step 2.
9. The Naviextras toolbox recommends to do an update. This update is needed to update your navigation system with anything from naviextras.com!
10. After this update you can install any map, etc. offered by naviextras.com.